



97 Central Park Drive, Henderson
Auckland, New Zealand
Phone: 09 838-9800
Fax: 09 838-6937
Email: info@splashequip.co.nz
www.splashequip.co.nz

EXAMPLES OF SPECIFIC JOB USE

HOUSEWASHING:

Spray with Housewash chemical, Moss or Lichen Killer. Leave for 10 minutes without allowing to dry. Wash off with waterblaster set at 1000 to 1500 psi at minimum of 11 litres per minute and maximum 30 litres per minute.

PREPAINT BLASTING: Chemicals are not required.

Blast surface using 3000 psi at 15 to 30 litres/ minute. This will remove all old paint and contamination that is going to come off. Anything left behind is well adhered and may be sanded or painted over. Take care on wooden surfaces not to damage and “fur” the wood. Also, around wooden joinery, not to blast out the putty and damage the paint, or force water through the windows to the inside of the building.

PAINT STRIPPING:

For total removal of paint from hard surfaces higher pressures, using a rotary head are the most effective. Lower pressures and volumes for softer paints or softer surfaces, such as concrete, bricks and concrete blocks with higher pressures and volumes for steelwork. For timber surfaces use paint strippers to soften paint and blast off at 3000 psi with a standard fan jet.