



97 Central Park Drive, Henderson
Auckland, New Zealand
Phone: 09 838-9800
Fax: 09 838-6937
Email: info@splashequip.co.nz
www.splashequip.co.nz

EXAMPLES OF SPECIFIC JOB USE

CEDAR TIMBER CLEANING:

Natural cedar requires the application of a special timber cleaning chemical followed by a gentle waterblast at 800 psi. Cedar is very soft and easily damaged but can be very effectively, and easily, cleaned with the correct treatment. Stained Cedar can be cleaned using a low pressure blast with Housewash Chemical. However stain that has deteriorated may well come off.

For the removal of stain use timber cleaning chemical followed by either paint stripper or hot waterblast at 800 psi to remove residue.

CONCRETE SURFACE AREAS

Use a Rotomajic surface cleaner with a waterblaster at 3000 psi, 15 to 30 litres per minute. This will give clean even coverage with no lines or gun streaks, whilst being about four times faster and far easier physically to use than a gun. Flush surface off with gun or hose. For smaller areas gun cleaning is satisfactory, however care must be taken not to be too severe and remove the top surface of the concrete as this releases the surface tension and allows the concrete to eventually crack.